



Official Lane Maintenance and Capital Equipment Provider

DIRECT+
Conditioning System



ENVOY



AUTHORITY22

Select Machine

Pattern Information

Date

Pattern Type

Pattern Difficulty

Pattern Designer

Pattern Volume (ml)

Pattern Parameters

Pattern Number

Pattern Name

Mode

Forward Speed

Start Cleaner Spray

Start Squeegee

Start Oiling

Split Pattern

Supplies Information

Lane Cleaner

Cleaner Mixture Ratio

Cleaner Transition Distance Authority22

Cleaner Spray End Distance Envoy

Lane Conditioner

Surface Information

Surface Type

Surface Brand

Age

Notes

Zone	1	2	3	4	5	6	7	8
Zone End Distance	10	17	23	29	33,5	41		
Zone Ratio	L 1,9 : 1	2,1 : 1	2,3 : 1	2,4 : 1	3,1 : 1	1,0 : 1	### : 1	### : 1
	R 1,9 : 1	2,1 : 1	2,6 : 1	2,6 : 1	3,8 : 1	1,0 : 1	### : 1	### : 1
Zone Volume (ml)	10,31	5,99	3,66	2,15	0,83	0,00	0,00	0,00

ZONE	7 Pin Side																	Board Number												10 Pin Side											
	L1	L2	L3	L4	L5	L6	L7	L8	L9	L10	L11	L12	L13	L14	L15	L16	L17	L18	L19	C20	R19	R18	R17	R16	R15	R14	R13	R12	R11	R10	R9	R8	R7	R6	R5	R4	R3	R2	R1		
1	35	35	35	35	40	45	50	55	65	75	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	80	75	65	55	50	45	40	35	35	35	35			
2	30	30	30	30	30	30	35	40	55	65	68	68	68	68	68	68	68	68	68	68	68	68	68	68	68	68	68	65	55	40	35	30	30	30	30	30	30	30			
3	22	22	22	22	22	22	22	22	29	40	48	52	52	52	52	52	52	52	52	52	52	52	52	52	52	52	52	48	40	29	20	20	20	20	20	20	20	20			
4	13	13	13	13	13	13	13	13	15	17	22	27	30	32	32	32	32	32	32	32	32	32	32	32	32	32	30	27	22	17	12	12	12	12	12	12	12	12			
5	6	6	6	6	6	6	6	6	6	7	8	9	11	15	17	19	19	19	19	19	19	19	19	19	19	19	17	15	12	9	5	5	5	5	5	5	5	5			
6	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1		
7																																									
8																																									

